



SMART ASSISTANT: THE BECKER TOOL

The timesaving commissioning tool.

QUALITY
made in Germany



BECKER
for you. forever.


WHAT MAKES IT SPECIAL: THE BENEFITS AT A GLANCE.

JUST SIMPLE. THE BECKER TOOL.

Devices can be identified with a simple tap

All important information about the installed products at a glance

Simple setting of the threshold values, sun protection properties and special functions



Available software updates are displayed automatically and can be easily transferred wirelessly

Clear visualisation and selection of all drives, sensors and receivers in one installation

Settings can be easily transferred to other devices



Here is a small insight into the functions!



Click here to download!

Discover the Becker tool - the simple and smart solution for quick and easy commissioning of your Becker products! This free tool allows you to configure drives and controls and adjust settings with just a few clicks. Whether you want to set end positions, manage special functions, adjust astro functions or network sensors with sun shading applications - the Becker tool makes it easy for you.

Simply download it now and connect it to your notebook, tablet or smartphone using a Bluetooth®-enabled device or a CentronicPlus USB stick. Benefit from functions such as the precise setting of threshold values, the operation of timers and the maintenance and analysis of your CentronicPlus installations.

The Becker tool saves time and increases the efficiency of your projects. Make commissioning child's play!



Depending on the device, simply connect via CentronicPlus USB wireless stick or Bluetooth®

More functions in detail

- Programming of transmitters and assignment of channels possible
- Linking sensors with drives or controllers
- Operation of the products via CentronicPlus radio or Bluetooth® possible
- Saving and deleting freely selectable intermediate positions
- Adaptation of the device names for correct display on digital operating devices
- Saving and deleting end positions and running times
- Setting memory times
- Operation across the entire installation
- Management of drive and control locks and winter modes
- Radio settings, such as targeted learning readiness or resets



BECKER-Antriebe GmbH

Drives and control units for
roller shutters, sun protection
and Extended Applications

Friedrich-Ebert-Straße 2–4
D-35764 Sinn

Tel.: 02772/507-0
Fax: 02772/507-110

www.becker-antriebe.com
info@becker-antriebe.com



BECKER
for you. forever.